


OVERHAUL




1. REMOVE PROPELLER W/CENTER BEARING SHAFT ASSY


- (a) Depress the brake pedal and hold it.
- (b) Using a hexagon wrench (6 mm), loosen the cross groove joint set bolts 1/2 turn.

HINT:

Put a piece of cloth inside the cross groove joint cover so that the boot does not touch the inside of the cross groove joint cover.




- (c) Place matchmarks on the propeller shaft sub-assy and differential carrier assy.
- (d) Remove the 4 bolts and washers, separate the propeller shaft sub-assy.



- (e) Remove the 2 bolts and 2 bearing washer No.2, separate the propeller w/ center bearing shaft assy.
- (f) Pull out the propeller w/ center bearing shaft assy from the transfer.

NOTICE:


- When removing the propeller shaft, do not apply a large force to the universal joint.
- During and after the removal of the propeller shaft, keep the universal joint angle straight (within 15 degrees).
- Be careful not to damage the oil seal.



- (g) Insert SST into the transfer to prevent oil leakage.
SST 09325-20010

NOTICE:

Be careful not to damage the oil seal.




2. REMOVE INTERMEDIATE SHAFT

- (a) Place matchmarks on the propeller shaft sub-assy and universal joint flange.

NOTICE:

Do not place the matchmarks with a punch.

- (b) Using a hexagon wrench (6 mm), remove the 6 bolts and 2 washers to separate intermediate shaft sub-assy and propeller shaft sub-assy.



3. INSPECT INTERMEDIATE SHAFT


- (a) Using a dial indicator, inspect the intermediate shaft sub-assy.

Maximum runout: 0.4 mm (0.016 in.)

NOTICE:


The dial indicator must be set at a right angle to the center of the propeller shaft.

If the shaft runout is greater than the maximum, replace the propeller w/ center bearing shaft assy.




- (b) Using a dial indicator, inspect the rear side of universal joint flange runout in the vertical direction.

Maximum runout: 0.1 mm (0.004 in.)



- (c) Using a dial indicator, inspect the rear side of universal joint flange runout in the horizontal direction.

Maximum runout: 0.1 mm (0.004 in.)



4. INSPECT PROPELLER SHAFT


- (a) Using a dial indicator, inspect the propeller shaft sub-assy.

Maximum runout: 0.4 mm (0.016 in.)

NOTICE:

The dial indicator must be set at a right angle to the center of the propeller shaft.

If the shaft runout is greater than the maximum, replace the propeller w/ center bearing shaft assy.




- 5. REMOVE CENTER SUPPORT BEARING ASSY NO.1**
- Using a hammer and a chisel, loosen the staked part of the nut.
 - Using a soft vise to hold the universal joint flange, remove the nut and washer.

NOTICE:

Do not overtighten the vise.

- Place matchmarks on the universal joint flange and intermediate shaft sub-assy.




- Using SST, remove the universal joint flange.
SST 09950-40011 (09951-04020, 09952-04010, 09953-04030, 09954-04010, 09955-04061, 09957-04010, 09958-04011)

NOTICE:


Be careful not to damage the universal joint flange.

- Remove the center support bearing assy No.1 and washer.

**6. INSPECT CENTER SUPPORT BEARING ASSY NO.1**

- Turn the center support bearing assy No.1 by hand with applying force in the rotation direction. Check the bearing turns smoothly.
- Check that the seals and bracket are not cracked or damaged.

If the center support bearing assy No.1 is damaged, worn, or does not turn freely, replace it.


**7. INSTALL CENTER SUPPORT BEARING ASSY NO.1**

- Set the center support bearing No.1 on the intermediate shaft sub-assy as shown in the illustration.


NOTICE:

Be sure to install the bearing in the correct orientation.

- Install the new washer to the intermediate shaft sub-assy.



- Align the matchmarks on the universal joint flange and intermediate shaft sub-assy, place the flange on the shaft.



- (d) Using a soft vise to hold the universal joint flange, press the bearing into position by tightening down a new nut and washer.


Torque: 181.4 N·m (1,850 kgf·cm, 134 ft·lbf)

- (e) Loosen the nut.

- (f) Torque the nut again.

Torque: 68.6 N·m (700 kgf·cm, 51 ft·lbf)


- (g) Using a chisel and a hammer, stake the nut.



8. INSTALL INTERMEDIATE SHAFT

- (a) Align the matchmarks on the intermediate shaft sub-assy and propeller shaft sub-assy.

- (b) Using a hexagon wrench (6 mm), tighten the 6 bolts with 2 washers temporarily.




9. TEMPORARY TIGHTEN PROPELLER W/CENTER BEARING SHAFT ASSY

- (a) Remove SST from the transfer.


- (b) Insert the propeller w/ center bearing shaft assy.

NOTICE:

- **Be careful not to damage the oil seal.**
- **Be careful not to damage the universal joint boot when installing the propeller shaft.**




- (c) Align matchmarks on the propeller shaft sub-assy and differential carrier assy, install the 4 bolts and washers temporarily.




- (d) Connect the center support bearing assy No.1 with 2 bolts and 2 center support bearing washer No.2.

NOTICE:

Use the removed washers when installation.




- (e) Tighten the 4 bolts.
Torque: 73.5 N·m (749 kgf·cm, 54 ft·lbf)




10. FULLY TIGHTEN PROPELLER W/CENTER BEARING SHAFT ASSY

- (a) Remove the cloth from the universal joint.
- (b) Depress the brake pedal and hold it.
- (c) Using a hexagon wrench (6 mm), tighten the 6 bolts.
Torque: 27 N·m (275 kgf·cm, 20 ft·lbf)



- (d) With the vehicle in the unladen condition, adjust the dimension between the rear side of cover and the shaft, as shown in the illustration.




- (e) With the same condition, adjust the dimension between the rear side of center bearing housing and the rear side of cushion, as shown in the illustration.
- (f) Check that the center line of the bracket is at right angles at the shaft axial direction.
- (g) In case of being a strange sound or noise:
Select the center support bearing washer No.2 for adjusting.

NOTICE:

- **Make sure to use the washer of the same thickness on both right and left sides.**
- **Do not use 2 or more washers on a bolt.**

Washer thickness:

| Thickness mm (in.) | Thickness mm (in.) |
|--------------------|--------------------|
| 3.6 (0.142) | 6.5 (0.256) |
| 4.5 (0.177) | 9.0 (0.354) |



- (h) Tighten the 2 bolts.
Torque: 36.8 N·m (374 kgf·cm, 27 ft·lbf)