







Rear Wiper and Washer

System Outline

When the ignition SW is turned on and glass hatch is closed, the current flows through the WASHER fuse to TERMINAL 2 of the rear washer motor, the current flows through the RR WIPER fuse to IG relay (Point side) to TERMINAL 7 of the junction SW and TERMINAL 3 of the rear wiper relay.

1. Rear Wiper Normal Operation

When the ignition SW is turned on, glass hatch is closed and rear wiper SW turned to HI position, the current flows through the TERMINAL 3 of the rear wiper relay to TERMINAL 6 to TERMINAL 2 of the rear wiper SW to TERMINAL 5 to GROUND. As a result, the rear wiper relay is operated, and the current flows through the TERMINAL 3 of the rear wiper relay to TERMINAL 4 to TERMINAL 3 of the junction SW to rear wiper motor to TERMINAL 1 of the junction SW to GROUND, causing the motor to operate the rear wiper.

2. Rear Wiper Intermittent Operation

When the ignition SW is turned on, glass hatch is closed and rear wiper SW turned to LO position, the current flows through the TERMINAL 3 of the rear wiper relay to TERMINAL 2 to TERMINAL 1 of the rear wiper SW to TERMINAL 5 to GROUND. As a result, the intermittent circuit of the relay operates and the rear wiper motor operates.

3. Washer Operation

With the ignition SW is turned on, glass hatch is closed and rear washer SW turned to HI and on+ washer position, when the rear wiper SW is turned further, the current flows through the WASHER fuse to TERMINAL 2 of the rear washer motor to TERMINAL 1 to TERMINAL 3 of the rear washer SW to TERMINAL 5 to GROUND, so that the rear washer motor rotates and the window washer emits a water, only while the switch is fully turned.

With the ignition SW turned on and the rear wiper and washer SW turned to OFF position, when the washer is turned ON (to Wiper OFF side), current flows as above so that the rear washer motor rotates and the window washer emits water as well as the wiper operates.

: Parts Location

Code	See Page	Code	See Page	Code	See Page
C14	36	I10	37	J11	38
D4	36	J1	35	J12	38
D18	36	J2	37	R3	35
G5	38	J10	38	R13	39

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
ID	25	Floor Wire and Instrument Panel J/B (Lower Finish Panel)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
3B	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
4C	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA2	42	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)
ID1	42	Instrument Panel Wire and Floor Wire (Left Kick Panel)
ID2		
BC1	44	Back Door No.1 Wire and Floor Wire (Left Quarter Panel)
BC2		
BF1	44	Back Door No.1 Wire and Back Door No.2 Wire (Back Panel LH)
BF2		

: Ground Points

Code	See Page	Ground Points Location
IE	42	Behind Combination Meter
BH	44	Left Quarter Panel

