

## O : Parts Location

Code	See Page	Code	See Page	Code	See Page
J2	37	M2	37	V6	37
J7	37	P5	37		

### C : Relay Blocks

Code See Page Relay Blocks (Relay Block Location)   3 28 RH R/B (Right Side of the Instrument Panel Reinforcement)		-	
3 28 RH R/B (Right Side of the Instrument Panel Reinforcement)	Code	See Page	Relay Blocks (Relay Block Location)
	3	28	RH R/B (Right Side of the Instrument Panel Reinforcement)

#### Sunction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IG	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IH	25	
ЗA	- 29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3B		
4B	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)

# Sround Points

Code	See Page	Ground Points Location
IE	42	Behind Combination Meter
IG	42	Right Kick Panel