

182

COROLLA MATRIX (EM0350U)

O : Parts Location

Γ	Code	See Page	Code	See Page	Code	See Page
Γ	C17	36	J7	37		

C : Relay Blocks

 \bigcirc

 \backslash /

Code	See Page	Relay Blocks (Relay Block Location)
1	23	Engine Room R/B (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)	
IC	25	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)	
IF	25	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)	
IL	24		
ЗA	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)	
4C	32	Instrument Panel Wire and Center J/B (Behind the Combination Meter)	

: Ground Points

Code	See Page	Ground Points Location
IG	42	Right Kick Panel