

: Parts Location

Code	See Page	Code	See Page	Code	See Page
C11	36	F1	34	J2	37
C12	36	F2	34		
D2	36	l11	37		

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)	
1	23	Engine Room R/B (Engine Compartment Left)	

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
IG	25	
IH	25	
IK		Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
IL	24	
IM		
3B	29	Instrument Panel Wire and RH J/B (Right Side of the Instrument Panel Reinforcement)
3C	729	Instrument and wire and Kirob (Kight Side of the Instrument)

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
IA4	12	Engine Room Main Wire and Instrument Panel Wire (Instrument Panel Reinforcement LH)	
IA5	N5 42	Engine Noon Main whe and institution of a liet who (institution) in the Nethologonal CET)	

: Ground Points

Code	See Page	Ground Points Location
EA	40	Front Right Fender
EB	40	Front Left Suspension Tower
IE	42	Behind Combination Meter